chanhvinh.com

Choose one component from each of the coloured sections to assemble a complete switch.
For other options or further information please contact your local sales office.

BLOCK | LED | A ACCESSORIES

A Accessories



Aluminium protective cover for flush mount pushbutton with fitted spring, closed

Colour	Part No.
Red	704.928.12
Yellow	704.928.14
Blue	704.928.16
Natural	704.928.18



Aluminium protective cover for flush mount selector switch short lever with fitted spring, closed

Colour	Part No.
Natural	704.928.28



Aluminium protective cover for flush mount selector switch, lockable

	Part No.
Natural	704.928.38

A Accessories



Protective front ring with silicon membrane for raised or flush mount pushbutton

Part No.	Size
704.600.3	29mm Ø for raised pushbutton
704.955.3	35mm Ø for flush mount pushbutton



Emergency-stop protective shroud, yellow painted aluminium with 22.5mm mounting hole

Part No.
704.927.4



Emergency-stop switch label, 60mm diameter, English, German, French and Dutch

Part No.	Markings
704.963.6	Emergency stop
704.963.5	Not Aus
704.963.7	Arret D'urgence
007.963.6	Noodstop